



**SPANVALL**  
WORLD CLASS BEDDING

**SPANVALL**  
Bedding Spreader

**SPANVALL**  
Bedding Spreader

# SPANVALL MEDIUM SPREADER

 [www.spanvall.com](http://www.spanvall.com)

 + 45 70 26 01 81

# SPANVALL MEDIUM SPREADER

## PRODUCT DESCRIPTION

Spanvall Medium Spreader is specially designed for Spanvall bedding products for poultry farms.

The spreader is easy to adapt to a bobcat  
The adjustable harness is easy to replace with conventional screws, so it can be quickly and easily assembled with another loader or telescopic handler.


An adapter with three-point linkage is used for tractor. The spreader is hydraulically driven with a minimum output of 30 l/m oil flow

**Operates with hydraulic drive**

**2500 m<sup>2</sup> in 20-25 minutes**

**Spread very quickly, efficiently and conveniently**

**No manual work - Labour and time saving**



**Easy to adapt on a bobcat**

## HOW TO USE

1 Install the spreader to the bobcat



2 Put bedding in the spreading machine





3 Spread 1 cm the bedding



Scan to watch  
spreader in action



## MEASUREMENTS



Loading capacity: **1,4 m<sup>3</sup>**

Spreading wide: **5-6 m**

Net weight: **500 kg**

Gross weight: **550 kg**

HS code: **84368090**